

How to Replace a Toilet Fill Valve

Remove lid from tank.



Remove the old fill valve.



Shut off water by turning the shut-off valve clockwise.



The new fill valve will go on similar to how the old one came off.

Drain as much water out of tank as possible by holding flush lever down until toilet is completely flushed.



Reattach new fill valve and adjust float to correct height according to manufacturer's instructions.



Sponge or towel out any remaining water in the tank. A shop vac also works well.



Attach new refill tube to overflow pipe.

Disconnect the water supply tube or hose that connects the water supply valve to the fill valve.



Reattach water supply tube or hose to tank.



Beneath the tank, loosen the lock nut that holds the fill valve to the tank.



Turn on water, test new fill valve and check for leaks.